

Owner's Manual

DVD / CD Player

Model No. **DVD-S48**
DVD-S68



DVD-S68



If you have any questions contact

In the U.S.A. and Puerto Rico:

1-800-211-PANA (7262)

In Canada: 1-800-561-5505

U.S.A. and Puerto Rico:

The warranty can be found on page 14.

Please register via the Internet at:

www.Panasonic.com/register

Canada :

The warranty can be found on page 15.

Dear customer

Thank you for purchasing this product.

For optimum performance and safety, please read these instructions carefully.

Before connecting, operating or adjusting this product, please read the instructions completely.

Please keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

Read these operating instructions carefully before using the unit. Follow the safety instructions on the unit and the applicable safety instructions listed below. Keep these operating instructions handy for future reference.

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE SCREWS. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING

Unit

- To reduce the risk of fire, electric shock or product damage,
 - Do not expose this unit to rain, moisture, dripping or splashing.
 - Do not place objects filled with liquids, such as vases, on this unit.
 - Use only the recommended accessories.
 - Do not remove covers.
 - Do not repair this unit by yourself. Refer servicing to qualified service personnel.

AC power supply cord

- Install this unit so that the power cord can be unplugged from the socket outlet immediately if any problem occurs.

CAUTION

Unit

- This unit utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Placement

- To reduce the risk of fire, electric shock or product damage,
 - Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure this unit is well ventilated.
 - Do not obstruct this unit's ventilation openings with newspapers, tablecloths, curtains, and similar items.
 - Do not place sources of naked flames, such as lighted candles, on this unit.

Batteries

- Danger of explosion if battery is incorrectly replaced. Replace only with the type recommended by the manufacturer.
- When disposing the batteries, please contact your local authorities or dealer and ask for the correct method of disposal.
- Mishandling of batteries can cause electrolyte leakage and may cause a fire.
 - Do not mix old and new batteries or different types at the same time.
 - Do not heat or expose to flame.
 - Do not leave the battery(ies) in a car exposed to direct sunlight for a long period of time with doors and windows closed.
 - Keep the AAA R03 batteries out of reach of children to prevent swallowing.
 - Do not take apart or short circuit.
 - Do not recharge alkaline or manganese batteries.
 - Do not use batteries if the covering has been peeled off.
 - Remove batteries if you do not intend to use the remote control for a long period of time. Store in a cool, dark place.

THE FOLLOWING APPLIES ONLY IN THE U.S.A.

FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

Panasonic Corporation of North America
One Panasonic Way, Secaucus, NJ 07094

Support Contact:

Panasonic Consumer Electronics Company
Telephone No.: 1-800-211-PANA (7262)

CAUTION- VISIBLE AND INVISIBLE LASER RADIATION
WHEN OPEN.
DO NOT STARE INTO BEAM.

FDA 21CFR / CLASS II (IIa)

(Inside of product)

Table of contents

Getting started

IMPORTANT SAFETY INSTRUCTIONS	2
General Information	4
Accessories	4
Inserting the batteries	4
Region codes	5
Playable medias	5
Unit and disc care	5
Disc handling precautions	5
Connections	6
Control guide	8

Operations

Playback	9
USB REC	10
HDMI CEC protocol	10
Changing the player settings	11
SYSTEM	11
LANGUAGE	11
AUDIO	11
VIDEO	12
OTHER	12

Reference

Specifications	12
Troubleshooting	13
Limited Warranty (Only for U.S.A. and Puerto Rico)	14
Limited Warranty (Only for Canada)	15

General Information

Accessories

- ☐ 1 Audio/Video cable
(K2KA6BA00004)
- ☐ 1 Remote Control
(N2QAYA000014)
- ☐ 2 Batteries for remote control

(Only for Canada)


The enclosed Canadian French label sheet corresponds to the English display on the front and back side of the unit.

NOTE

- Product numbers correct as of December 2010. These may be subject to change.
- Only for U.S.A. and Puerto Rico:
To order accessories, refer to "Accessory Purchases (United States and Puerto Rico)" on page 14.
Only for Canada:
To order accessories, call the dealer from whom you have made your purchase.

Inserting the batteries

Insert so the poles (+ and -) match those in the remote control.



R03, AAA

(Alkaline or manganese batteries)

The model number and serial number of this product can be found on either the back or the bottom of the unit. Please note them in the space provided below and keep for future reference.

MODEL NUMBER _____
SERIAL NUMBER _____

Region codes

DVD-Video

This unit plays DVD-Video marked with labels containing the region number “1” or “ALL”.

Example: 

Playable medias

You can play back the following medias:

DVD Video	DVD-Video format
DVD-R	DVD-Video format* ¹ ,
DVD-R DL	JPEG* ² * ³ , MP3* ⁴ , DivX* ⁵ * ⁶ * ⁷ * ⁸
DVD-RW	DVD-Video format* ¹
+RW	Video* ¹
+R	
+R DL	
CD-Audio	CD-DA, Video CD, Super Video CD
CD-R	CD-DA, JPEG* ² * ³ , MP3* ⁴ ,
CD-RW	Video CD, Super Video CD, DivX* ⁵ * ⁶ * ⁷ * ⁸
USB	MP3* ⁴ , JPEG* ² * ³ , DivX* ⁵ * ⁶ * ⁷ * ⁸

*¹ Finalizing is necessary.

*² The file extension has to be ‘.JPG’ or ‘.JPEG’.

*³ Files that have been altered, edited or saved with computer picture editing software may not be displayed.

*⁴ The file extension has to be ‘.mp3’.

*⁵ Model for Canada only

*⁶ The file extension has to be ‘.DIVX,’ ‘.divx,’ ‘.AVI,’ or ‘.avi’.

*⁷ (Only for Canada)

Certified to the DivX Home Theater Profile V3.0.

GMC (Global Motion Compensation) not supported.

*⁸ (Only for Canada)

Subtitle text file is not supported.

NOTE

- It may not be possible to play the medias in some cases due to the type of media, the condition of the recording, the recording method and how the files were created.

(For USB devices)

- This unit does not guarantee connection with all USB devices.
- This unit does not support USB device charging.
- FAT12, FAT16 and FAT32 file systems are supported.
- This unit supports USB2.0 High Speed.

Unit and disc care

Clean this unit with a soft, dry cloth

- Never use alcohol, paint thinner or benzine to clean this unit.
- Before using chemically treated cloth, read the instructions that came with the cloth carefully.
- Cleaning of the lens is generally not necessary although this depends on the operating environment.
- Do not use commercially available lens cleaners as they may cause malfunction.

Clean discs

- Wipe with a damp cloth and then wipe dry.



Disc handling precautions


- Handle discs by the edges to avoid inadvertent scratches or fingerprints on the disc.
- Do not attach labels or stickers to discs.
- Do not use record cleaning sprays, benzine, thinner, static electricity prevention liquids or any other solvent.
- Do not use the following discs:
 - Discs with exposed adhesive from removed stickers or labels (rented discs etc.).
 - Discs that are badly warped or cracked.
 - Irregularly shaped discs, such as heart shapes.
- The digital audio content side of a DualDisc does not meet the technical specifications of the Compact Disc Digital Audio (CD-DA) format so playback may not be possible.

Connections


Before making any connections we suggest you temporarily disconnect all the units from AC power.

- Do not place the unit on amplifiers/receivers or equipment that may become hot. The heat can damage the unit.
- Do not connect video signals through a video recorder. Due to copy guard protection the picture may not be displayed properly.

DVD-S48



DVD-S68



NOTE for AC power supply cord

- This unit consumes a small amount of AC power even when turned off. In the interest of power conservation, if you will not be using this unit for an extended period of time, it can be disconnected.

NOTE for HDMI (DVD-S68 only)


- AUDIO terminals become impossible to use according to the kind of the cable that you use.

NOTE for COMPONENT VIDEO OUT

- Set "Video" to "Progressive" (→ page 11).


DVD-S48

VIDEO OUT




- Connect terminals of the same color.

COMPONENT VIDEO OUT




- Connect terminals of the same color.

VIDEO OUT




- Connect terminals of the same color.

COMPONENT VIDEO OUT





- Connect terminals of the same color.

HDMI



With HDMI compatible amplifier





- ① **POWER** , **POWER** /I
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.

DISPLAY

Displays information on TV screen during playback

OPEN/CLOSE

Opens/closes the disc tray

- ② **0-9, ≥10**

To select title/chapter/track numbers etc.

e.g., 5: 5
15: ≥10 → 1 → 5

SEARCH MODE

Starts to select the point

1. Press to select the item.
2. Press **0** to **9** to specify the location.
3. Press **OK**.

- ③ **TOP MENU**

Shows Top menu

MENU

- Shows Menu
- Sets PBC of VCD equipped with Playback Control (PBC) function to On/Off
▲ ▼ ◀ ▶
- Selects items, input position, etc.
 - For moving the display position of enlarged images
 - For rotating JPEG images

OK

Confirms menu selection

SETUP

Enters or exits the system setup menu
(→ page 11)

RETURN

Returns to the previous display

- ④ **SKIP,**

- Skips to previous title/chapter/track or next title/chapter/track
- Switches the MENU page of VCD equipped with Playback Control (PBC) function

SEARCH,

Starts fast reverse or fast forward

STOP

Stops playback

PLAY/PAUSE

Starts or pauses playback

Starts playback

FRAME II

Plays Video frame by frame

- ⑤ **REPEAT**

Selects various repeat mode

Selectable modes differ depending on the type of contents. REP DIR plays all the same type of files in the selected folder repeatedly.

A-B REPEAT

Repeats playback from point A to B on a media

SLOW

Starts slow motion playback

CANCEL

Clear the input information

- ⑥ **SUBTITLE**

Shows the subtitle and selects different subtitle

RANDOM/ANGLE

Starts random playback/Switches the camera angle

AUDIO

Changes soundtracks

ZOOM

Changes zoom ratio

PROGRAM

Sets the playback order

1. Press **▲ ▼ ◀ ▶** to select the item.

2. Press **0** to **9** to specify the order.

To cancel: Press **CANCEL**.

3. Press **▲ ▼ ◀ ▶** to select **PLAY**.

To clear the whole program:

Press **▲ ▼ ◀ ▶** to select **CLEAR**.

4. Press **OK**.

USB

Switches to the USB mode / Returns to the disc mode

USB REC

Performs USB REC

- ⑦ Disc tray


When inserting a media, ensure that it is facing the right way up.

- ⑧ USB port

Connects a USB device

Playback

- 1 Turn on the TV and select the correct video input.
- 2 Press **POWER** .
- 3 Place a disc or connect a USB device.



- If this unit is not switched to the USB mode when connecting the USB device, press **USB** and press   to select the item.
- 4 Press     to select the item and press **OK**.
 - Depending on the disc, playback may start automatically. (JPEG only)
 - When you press **PLAY/PAUSE**   instead of **OK**, you can start the slide show.

Stopping playback

Press **STOP** .

→ The stopped position is memorized.

Resume play function

Press **PLAY/PAUSE**   to restart from this position.

→ The position is cleared if the tray is opened or you press **STOP**  several times to display '■' on TV's display.

NOTE

- Screen saver will start automatically if the media playback is stopped and the menu is closed for about 5 minutes.
- The player will automatically switch to Power Standby mode if you do not press any buttons for about 25 minutes after the media has stopped playing.
- (DVD-S48)
Video images of the copyright-protected DivX® contents stored on a USB device cannot be output.
- (DVD-S68)
Video images of the copyright-protected DivX® contents stored on a USB device can be output only through the HDMI output terminal.

ABOUT DIVX VIDEO (Only for Canada)

- DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND (Only for Canada)

- This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.
- You can only play DivX videos that were rented or purchased with the DivX registration code of this DVD player. For details, Changing the player settings > OTHER (→ page 12).


Regarding DivX VOD content that can only be played a set number of times (Only for Canada)

- Some DivX VOD content can only be played a set number of times. When you play this content, the remaining number of plays is displayed.


USB REC

You can copy audio files (CD-DA) from a CD on a USB device into MP3 format.

- ① Connect the USB device.
- ② Play an audio CD.
- ③ During play, press **USB REC**.
- ④ Press ◀▶ to select “YES”, and press **OK**.



- ⑤ Press ▲▼◀▶ to select “TRACKS”.
 - In the default setting, all tracks are checked.
 - To remove each check mark, select the track by pressing ▲▼◀▶, and press **OK**.
 - To clear all the check marks, select the check mark at the top and press **OK**.



- ⑥ Press ▲▼◀▶ to select “START”, and press **OK** to begin copying.
 - You can change to preferred settings in the “OPTIONS” menu.
 - To exit the menu, select “QUIT”, and then press **OK**.

HDMI CEC protocol

(DVD-S68 only)

The DVD player supports HDMI CEC (Consumer Electronics Control) protocol.

Panasonic does not guarantee 100 % interoperability with all HDMI CEC devices.

- Set HDMI CEC to “On” (➔ page 11).

One Touch Play

When a video disc is placed in the unit and you press **POWER** ⏻, it turns on the TV, then disc play starts.

System Standby

When you turn off the TV, all connected HDMI CEC devices switch to standby mode simultaneously.

Control with TV’s remote control

The ability to control “Playback Control”, “Disc Menu Control” and “Device Select”.

For details, see the Operating Instructions for your TV.

Changing the player settings

Change the unit's settings if necessary. The settings remain intact even if you switch the unit to standby.

- ① Press **SETUP**.
- ② Press **▲▼** to select the menu, and press **▶**.
- ③ Press **▲▼** to select the item, and press **▶** to confirm your selection.
- ④ Press **▲▼** to select the settings, and press **OK**.

- To return the previous menu, press **◀**.
- To exit, press **SETUP**.

Operation methods other than the above procedure may be displayed. In that case, follow the on-screen instructions.

Depending on the type of media, this unit's settings may be disabled.

SYSTEM

TV System

⇒ This menu contains the options for selecting the color system that matches the connected TV.

NTSC

⇒ It will change the video signal of a PAL contents and output it to NTSC format.

PAL

⇒ It will change the video signal of an NTSC contents and output it to PAL format.

PAL60

⇒ It will change the video signal of an NTSC contents and output it to PAL 60 format.

Auto

⇒ Select this if the connected TV is compatible with both NTSC and PAL.

Screen Saver

⇒ This setting enables the Screen Saver to activate. Screen saver will start automatically if the media playback is stopped for about 5 minutes.

Video

⇒ This sets the output method of this unit according to the television to connect.

Resolution (DVD-S68 only)

⇒ Select a video resolution that is compatible with the TV display capability. Selecting **Auto** can automatically select the best resolution.

HDMI CEC (DVD-S68 only)

⇒ When connecting this unit with the TV via the HDMI cable, linked operations with a connected device is possible.

TV Type

⇒ Set the TV Type on the DVD player according to the TV you have connected.

4:3PS

⇒ 16:9 aspect images are enlarged in full screen with the both sides cut.

4:3LB

⇒ 16:9 aspect images are displayed with black bands on top and bottom.

16:9

⇒ 4:3 aspect images are displayed in the center of the screen.

16:9Full

⇒ 4:3 aspect images are stretched to right and left.

LANGUAGE

OSD

⇒ This switches the language for display menu.

Audio

⇒ This switches the language for output audio.

Subtitle

⇒ This switches the language for subtitle.

Menu

⇒ This switches the language for disc menu.

AUDIO

Audio Out (DVD-S68 only)

⇒ This sets the audio output method when connected to the "HDMI AV OUT" terminal.

Bitstream

⇒ When the connected equipment is supporting Dolby Digital

PCM

⇒ When the connected equipment is not supporting Dolby Digital

Dynamic Range

⇒ Adjusts for clarity even when the volume is low through compressing the range of the lowest sound level and the highest sound level.

Changing the player settings

VIDEO

Brightness

⇒ This adjusts the brightness.

Contrast

⇒ This adjusts the contrast.

Hue

⇒ This adjusts the color tone.

Saturation

⇒ This adjusts the saturation.

Sharpness

⇒ This adjusts the sharpness of the image outline.

OTHER

Rating

⇒ This sets the playback limitation level for DVD video discs. Selecting "8 No Limit" can play all discs.

Password

⇒ The password is required when setting or canceling the playback limitation or restoring the unit to the factory default. When doing this for the first time, key in "0000".
If you forget your old four-digit password, key in "0000".

(Only for Canada)

DivX(R) VOD

⇒ DivX VOD (Video On Demand) registration code allows you to rent and purchase movies using the DivX VOD service from the internet. For more information, visit Web Site ; <http://vod.divx.com>.

Black Level

⇒ Adjusting the black level control to the desired setting for picture enhancement.

Default

⇒ This restores the unit to the factory default settings.

Specifications

Signal system: NTSC/PAL

Operating temperature range:
+5 °C to +35 °C (+41 °F to +95 °F)

Operating humidity range:
20 % to 80 % RH (no condensation)

Video output:

Output level: 1.0 Vp-p (75 Ω)

Output connector: Pin jack (1 system)

Component video output:
(480p/480i: 60 Hz)
(576p/576i: 50 Hz)

Y output level: 1.0 Vp-p (75 Ω)

P_B output level: 0.7 Vp-p (75 Ω)

P_R output level: 0.7 Vp-p (75 Ω)

Output connector:
Pin jack (Y: green, P_B: blue, P_R: red)
(1 system)

Audio output:

Output level: 2 Vrms (1 kHz, 0 dB)

Output connector: Pin jack

Number of connectors: 2 channel: 1 system

USB slot: USB2.0: 1 system

[DVD-S68] HDMI AV output:

Output format: 480p/576p/1080i/720p/1080p

Output Connector: Type A (19 pin)

• This unit supports "HDMI CEC" function.

LASER Specification

Class I LASER Product:

Wave Length:
770 to 800 nm (CD)/645 to 660 nm (DVD)

Power supply: AC 120 V, 60 Hz

Power consumption: Approx. 12 W

Power consumption in standby mode:
Less than 1 W

Dimensions (W x D x H):

[DVD-S48] 360 mm x 209 mm x 38 mm
(Approx. 14 3/16" x 8 7/32" x 1 1/2")

[DVD-S68] 430 mm x 209 mm x 38 mm
(Approx. 16 15/16" x 8 7/32" x 1 1/2")

Mass (Weight):

[DVD-S48] Approx. 1.41 kg (3.11 lbs)

[DVD-S68] Approx. 1.56 kg (3.44 lbs)

Specifications are subject to change without notice.

Troubleshooting

Before requesting service, make the following checks. If you still need assistance, please contact us.

- U.S.A. and Puerto Rico: See page 14.
- Canada: See page 15.

To reset

Images from this DVD player do not appear on the television.

You forget your password.

- ⇒ Reset the DVD player to the factory defaults.
 - 1) Press **POWER**  on the DVD player to turn it on.
 - 2) Press **OPEN/CLOSE**  to open the disc tray.
 - 3) Press and hold **■** and **▶** on the DVD player at the same time for more than 5 seconds with the tray open.All the settings return to the factory preset.

No picture./No sound.

- ⇒ Check the video connection between the DVD player and the TV.
- ⇒ Turn on your TV and set to the correct in channel for the DVD player.

Remote control does not work.

- ⇒ Aim the remote control directly at the sensor on the front of the DVD player.

The screen is distorted. Noise occurs.

- ⇒ Check if the TV System setting is correct.

Discs cannot be played back.

- ⇒ Check for any scratches or smudges on the disc. If the disc is dirty, clean the disc.

Not able to select some items in the setup/system menu.

- ⇒ Press **STOP**  twice before selecting the setup/system menu.
- ⇒ Depending on the disc availability, some menu items cannot be selected.

When the following messages on the unit's display.

 **(LOAD)**

- ⇒ Loading the media. Wait a moment.

 **(STOP)**

- ⇒ Stopping the playback.



- ⇒ There is no disc, or a disc that cannot be played has been inserted.

 **(OPEN)**

- ⇒ The tray is open.

 **(TITLE)**

- ⇒ The disc title is displayed.
Press **▲ ▼ ◀ ▶** to select the title, then press **OK**.

 **(NOUSB)**

- ⇒ There is no USB device in USB mode.

Limited Warranty (Only for U.S.A. and Puerto Rico)

Panasonic Consumer Electronics Company,
Division of Panasonic Corporation of North America
One Panasonic Way, Secaucus, New Jersey 07094

Panasonic Blu-ray and DVD Products Limited Warranty

Limited Warranty Coverage (For U.S.A. and Puerto Rico Only)

If your product does not work properly because of a defect in materials or workmanship, Panasonic Consumer Electronics Company (referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your product with new or refurbished parts, (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by the warrantor.

Product or Part Name	Parts	Labor
Blu-ray Disc Player	1 year	90 days
Blu-ray Home Theater System	1 year	1 year
DVD Player	1 year	90 days
DVD Recorder	1 year	90 days
Rechargeable Batteries (pack), DVD-RAM Disc (defective exchange)	10 days	Not Applicable

During the "Labor" warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. This Limited Warranty excludes both parts and labor for non-rechargeable batteries, antennas, and cosmetic parts (cabinet). This warranty only applies to products purchased and serviced in the United States or Puerto Rico. This warranty is extended only to the original purchaser of a new product which was not sold "as is".

Mail-In Service

For assistance in the U.S.A. and Puerto Rico in obtaining repairs, please ship the product prepaid to:

Panasonic Exchange Center
4900 George McVay Drive
Suite B
McAllen, TX 78503
panacare@us.panasonic.com

When shipping the unit, carefully pack, include all accessories, and send it prepaid, adequately insured and preferably in the original carton. If Lithium Ion batteries are shipped by air the package must be labeled "Contains Lithium Ion Battery (No lithium metal)". Damaged batteries are prohibited from shipment by US Mail. Batteries must be securely packed in a manner to prevent short-circuiting and a package cannot contain more than 3 Lithium Ion batteries. Include a letter detailing the complaint, a return address and provide a daytime phone number where you can be reached. A valid registered receipt is required under the Limited Warranty.

IF REPAIR IS NEEDED DURING THE WARRANTY PERIOD, THE PURCHASER WILL BE REQUIRED TO FURNISH A SALES RECEIPT/ PROOF OF PURCHASE INDICATING DATE OF PURCHASE, AMOUNT PAID AND PLACE OF PURCHASE. CUSTOMER WILL BE CHARGED FOR THE REPAIR OF ANY UNIT RECEIVED WITHOUT SUCH PROOF OF PURCHASE.

Limited Warranty Limits And Exclusions

This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Factory Service Center or other Authorized Servicer, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE".

THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY.

(As examples, this excludes damages for lost time, travel to and from the servicer, loss of or damage to media or images, data or other memory or recorded content. The items listed are not exclusive, but for illustration only.)

ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Service Center. If the problem is not handled to your satisfaction, then write to the warrantor's Consumer Affairs Department at the addresses listed for the warrantor.

PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.

Customer Services Directory (United States and Puerto Rico)

Obtain Product Information and Operating Assistance; locate your nearest Dealer or Service Center; purchase Parts and Accessories; or make Customer Service and Literature requests by visiting our Web Site at:

<http://www.panasonic.com/help>

or, contact us via the web at:

<http://www.panasonic.com/contactinfo>

You may also contact us directly at:

1-800-211-PANA (7262),

Monday-Friday 9 am-9 pm; Saturday-Sunday 10 am-7 pm, EST.

For hearing or speech impaired TTY users, TTY: 1-877-833-8855

Accessory Purchases (United States and Puerto Rico)

Purchase Parts, Accessories and Instruction Books online for all Panasonic Products by visiting our Web Site at:

<http://www.pstc.panasonic.com>

Or, send your request by E-mail to:

npcparts@us.panasonic.com

You may also contact us directly at:

1-800-332-5368 (Phone) 1-800-237-9080 (Fax Only)

(Monday – Friday 9 am to 9 pm, EST.)

Panasonic Service and Technology Company

20421 84th Avenue South, Kent, WA 98032

(We accept Visa, MasterCard, Discover Card, American Express, and Personal Checks)

For hearing or speech impaired TTY users, TTY: 1-866-605-1277

As of November 2009

Limited Warranty (Only for CANADA)

Panasonic Canada Inc.
5770 Ambler Drive, Mississauga, Ontario L4W 2T3

PANASONIC PRODUCT – LIMITED WARRANTY

EXCHANGE PROGRAM

Panasonic Canada Inc. warrants this product to be free from defects in material and workmanship under normal use and for a period as stated below from the date of original purchase agrees to, at its option either (a) repair your product with new or refurbished parts, (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by Panasonic Canada Inc.

Panasonic Portable / Clock Radio (without Tape, CD, MD)	One (1) year
Panasonic Audio Product	One (1) year
Panasonic DVD Product	One (1) year
Accessories including rechargeable batteries	Ninety (90) days

This warranty is given only to the original purchaser, or the person for whom it was purchased as a gift, of a Panasonic brand product mentioned above sold by an authorized Panasonic dealer in Canada and purchased and used in Canada, which product was not sold "as is", and which product was delivered to you in new condition in the original packaging.

IN ORDER TO BE ELIGIBLE TO RECEIVE WARRANTY SERVICE HEREUNDER, A PURCHASE RECEIPT OR OTHER PROOF OF DATE OF ORIGINAL PURCHASE, SHOWING AMOUNT PAID AND PLACE OF PURCHASE IS REQUIRED

LIMITATIONS AND EXCLUSIONS

This warranty **ONLY COVERS** failures due to defects in materials or workmanship, and **DOES NOT COVER** normal wear and tear or cosmetic damage. The warranty **ALSO DOES NOT COVER** damages which occurred in shipment, or failures which are caused by products not supplied by Panasonic Canada Inc., or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Authorized Servicer, or damage that is attributable to acts of God.

Dry cell batteries are also excluded from coverage under this warranty.

THIS EXPRESS, LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL PANASONIC CANADA INC. BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. (As examples, this warranty excludes damages for lost time, travel to and from the Authorized Servicer, loss of or damage to media or images, data or other memory or recorded content. This list of items is not exhaustive, but for illustration only.)

In certain instances, some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or the exclusion of implied warranties, so the above limitations and exclusions may not be applicable. This warranty gives you specific legal rights and you may have other rights which vary depending on your province or territory.

CONTACT INFORMATION

For product information and operation assistance, please contact:

Our Customer Care Centre: Telephone #: 1-800-561-5505
 Fax #: (905) 238-2360
 Email link: "Support → contact us → email" on www.panasonic.ca

For defective product exchange within the warranty period, please contact the original dealer or our Customer Care Centre.

"DVD Logo" is a trademark of DVD Format/Logo Licensing Corporation.

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

DivX®, DivX Certified® and associated logos are trademarks of DivX, Inc. and are used under license.

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson.

The recording and playback of content on this or any other device may require permission from the owner of the copyright or other such rights in that content. Panasonic has no authority to and does not grant you that permission and explicitly disclaims any right, ability or intention to obtain such permission on your behalf. It is your responsibility to ensure that your use of this or any other device complies with applicable copyright legislation in your country. Please refer to that legislation for more information on the relevant laws and regulations involved or contact the owner of the rights in the content you wish to record or playback.



(Only for Canada)

(DVD-S68 only)



As an ENERGY STAR® Partner*, Panasonic has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

* For Canada only: The word "Participant" is used in place of the word "Partner".

-If you see this symbol-

Information on Disposal in other Countries outside the European Union



This symbol is only valid in the European Union.

If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

Panasonic Consumer Electronics Company, Division of Panasonic Corporation of North America
One Panasonic Way, Secaucus,
New Jersey 07094
<http://www.panasonic.com>

Panasonic Canada Inc.
5770 Ambler Drive
Mississauga, Ontario
L4W 2T3
www.panasonic.ca



VQT3L77
H1110MK0